



APPROVED CLEANERS



PATTERNS INCLUDE: Chambray, Guardian, Interlace, Kaleidoscope, Network, and Savoy II

Cleaner	Cleaner's MFG	Grey Scale ISO 105-A03	Stain Resistance
303 Fabric/Vinyl Cleaner (dilution: 1/2 cup (4 oz) in 1 gallon water)	303 Products, Inc.	4.5 - Slight color change	Class 4 - no staining
A&G Boat Wash & Multipurpose Cleaner (6:1 dilution)	A&G Industries, Inc.	4.5 - Slight color change	Class 4 - no staining
All Purpose Vinyl Cleaner	CMI Vclean	4.5 - Slight color change	Class 4 - no staining
Asepticare TB + II	Ecolab	4.5 - Slight color change	Class 4 - no staining
Babe's Boat Care Wash (dilution: 1 oz per gallon of water)	Babe's Boat Care Products	4.5 - Slight color change	Class 4 - no staining
Bio Kleen Amazing (dilution: 6 oz per gallon of water)	Bio Kleen Products Inc.	4.5 - Slight color change	Class 4 - no staining
Caviwipes XL Packed	Metrex	4 Moderate color change	Class 4 - no staining
Clorox Healthcare Bleach Germicidal Wipes	The Clorox Company	Not Approved- Does not pass stain release and top coat affected	
Crystal Simple Green - dilution 1:30	Sunshine Makers, Inc.	4.5 - Slight color change	Class 4 - no staining
Coverage Plus Germicidal Wipes	Spray Nine	4.5 - Slight color change	Class 4 - no staining
Dispatch (1:10 Dilution)	Caltech Industries Inc.	4.5 - Slight color change	Class 4 - no staining
Ducky All Purpose Cleaner	Ducky Products, Inc.	Stain resistance property affected-not approved	

Cleaner	Cleaner's MFG	Grey Scale ISO 105-A03	Stain Resistance
Fabric Cleaner	Tekonsha Corp.	4.5 - Slight color change	Class 4 - no staining
Fantastik® Antibacterial All Purpose Cleaner Heavy Duty	S.C. Johnson & Son, Inc.	4.5 - Slight color change	Class 4 - no staining
Finyl Fix Vinyl Cleaner - dilution: 0.5 oz / quart water	Neuco Seating Inc.	Not Approved- Does not pass stain release	
Formula 409® Antibacterial All-purpose cleaner	The Clorox Company	4.5 - Slight color change	Class 4 - no staining
Four Star All Purpose Cleaner	Four Star	Not Approved - color and hand change	N/A
Glance NA Diluted (1:50 water)	Diversey Inc.	4.5 - Slight color change	Class 4 - no staining
GP Forward Diluted (1:64 water)	Diversey Inc.	4.5 - Slight color change	Class 4 - no staining
Hydrogen Peroxide Cleaner Disinfectant Wipes	Clorox	4.5 - Slight color change	Class 4 - no staining
Lysol Foaming Disinfectant Cleaner	Brand, IC	4.5 - Slight color change	Class 4 - no staining
Mold & Mildew Stain Remover dilution: 1 scoop (1/2 oz) per quart water	Iosso Marine Products	4.5 - Slight color change	N/A
Mother's Leather Cleaner	Mothers	4.5 - Slight color change	Class 4 - no staining
Oxivir TB Wipes	Diversey Inc.	Surface spots and wear at Wyzenbeek 100,000 Cycles - Not approved	
Oxycide Diluted - 3 oz/ gl in water	Ecolab	4.5 - Slight color change	Class 4 - no staining

Cleaner	Cleaner's MFG	Grey Scale ISO 105-A03	Stain Resistance
Reposolv - Dilution: 1/40	American Continental Techlabs, LLC	4.5 - Slight color change	Class 4 - no staining
Sanicloth AF 3	PDI	4.5 - Slight color change	Class 4 - no staining
Simple Green Towels	Simple Green	4 Moderate color change	Class 4 - no staining
Sodium Hypochlorite Disinfectant/ Disinfectant Cleaner - Dilution: 0.5 oz / quart water	PCS - Process Cleaning Solutions	4.5 - Slight color change	Class 4 - no staining
Stride Floral Neutral (1:32 water) - Daily cleaning (1:64 water- Cleaning excess dirt)	Diversey Inc.	4.5 - Slight color change	Class 4 - no staining
Stride Fragrance Free Neutral Cleaner (1:266 water)	Diversey Inc.	4.5 - Slight color change	Class 4 - no staining
Super S	Tekonsha Corp.	4.5 - Slight color change	Class 4 - no staining
Super Sani-cloth	PDI	4.5 - Slight color change	Class 4 - no staining
Vinyl Sauce	Boat Blins	4.5 - Slight color change	Class 4 - no staining
Virex II 256 (1:256 Dilution)	Diversey Inc.	4.5 - Slight color change	Class 4 - no staining
Virox 5 Rtu	Diversey Inc.	4.5 - Slight color change	Class 4 - no staining
Wex Cide 128 (1:128 dilution)	Wexford Labs, Inc.	4.5 - Slight color change	Class 4 - no staining

Cleaner results are rated on a scale of 1 - 5	1-3: Causes discoloration. Not recommended	4-5: *Recommended for use
---	--	---------------------------

*Cleaners only recommended if diluted per manufacturer's instructions. Topical cleaners must be wiped off with clean water and dried with clean cloth following application. The performance results shown in this chart are not guaranteed for all SII Vinyl and Polyurethane products. The evaluations are indicators after laboratory tests and may not be indicative of field performance. Healthcare facilities maintain disinfecting regimens to reduce the spread of infections. There is a wide variety of available biocides that include bleaches, peroxides and quaternary ammonium products, among others. They should always be used at the recommended dilution, never in concentrated form. To prolong the life of digital or any other coated fabric, they should be rinsed off after the recommended residence time. It should be noted that misuse of disinfectants is the major source of surface deterioration. Spradling continually evaluates cleaners/ disinfectants. **Samples showed slight wear at Wyzenbeek 100,000 cycles

3/12/2019