



APPROVED CLEANERS

PERMABLOK®



PATTERNS INCLUDE: Apex, Finite, Gemini, Kilkenny Tweed, Patriot Plus, Prelude, Rave, Reflex MQ, Renaissance, Savoy, Scribe, Simtex, Sphere, Stratosphere, Trax

| Cleaner | Cleaner's Manufacturer | PERMABLOK® Grey Scale ISO 105-A03 | Cleaner | Cleaner's Manufacturer | PERMABLOK® Grey Scale ISO 105-A03 | Cleaner | Cleaner's Manufacturer | PERMABLOK® Grey Scale ISO 105-A03 |
|---|---------------------------|-----------------------------------|--|--------------------------|-----------------------------------|--|------------------------|-----------------------------------|
| 303 Fabric / Vinyl Cleaner (dilution: 1/2 cup (4 oz) in 1 gallon water) | 303 Products, Inc. | 4.5 Slight Color Change | Fabric Cleaner | Tekonsha Corp. | 4.5 Slight Color Change | Oxycide Diluted - 3 oz/gl in water | Ecolab | 4.5 Slight Color Change |
| A&G Boat Wash & Multipurpose Cleaner (6:1 dilution) | A&G Industries, Inc. | 4.5 Slight Color Change | Fanastatik® Antibacterial All Purpose Cleaner Heavy Duty | S.C. Johnson & Son, Inc. | 4.5 Slight Color Change | Sanicloth AF 3 | PDI | 4.5 Slight Color Change |
| All Purpose Vinyl Cleaner | CMI Vclean | 4.5 Slight Color Change | Formula 409® Antibacterial All-Purpose Cleaner | The Clorox Company | 4.5 Slight Color Change | Simple Green Towels | Simple Green | 4.5 Slight Color Change |
| Asepticare TB + 11 | Ecolab | 4.5 Slight Color Change | Glance NA Diluted (1:50 water) | Diversey Inc. | 4.5 Slight Color Change | Stride Floral Neutral (1:32 water) - Daily clean (1:64 water) - Clean excess dirt) | Diversey Inc. | 4.5 Slight Color Change |
| Babe's Boat Care Wash (dilution: 1 oz per gallon of water) | Babe's Boat Care Products | 4.5 Slight Color Change | GP Forward Diluted (1:64 water) | Diversey Inc. | 4.5 Slight Color Change | Stride Fragrance Free Neutral Cleaner (1:266 water) | Diversey Inc. | 4.5 Slight Color Change |
| Bio Kleen Amazing (dilution: 6 oz per gallon of water) | Bio Kleen Products Inc. | 4.5 Slight Color Change | Hydrogen Peroxide Cleaner Disinfectant Wipes | Clorox | 4.5 Slight Color Change | Super S | Tekonsha Corp. | 4.5 Slight Color Change |
| Caviwipes XL Packed | Metrex | 4 Moderate Color Change | Lustrell Faux Leather Care Kit - Lustrell Regular Cleaner | Warwick Lustrell | 4.5 Slight Color Change | Super Sani-cloth | PDI | 4.5 Slight Color Change |
| Crystal Simple Green (dilution 1:30) | Sunshine Makers, Inc. | 4.5 Slight Color Change | Lysol Foaming Disinfectant Cleaner | Brand, IC | 4 Moderate Color Change | Vinyl Sauce | Boat Bling | 4 Moderate Color Change |
| Coverage Plus Germicidal Wipes | Spray Nine | 4.5 Slight Color Change | Mold & Mildew Stain Remover dilution: 1 scoop (1/2 oz) per quart water | losso Marine Products | 4.5 Slight Color Change | Virex II 256 (1:256 dilution) | Diversey Inc. | 4.5 Slight Color Change |
| Dispatch (1:10 dilution) | Caltech Industries Inc. | 4.5 Slight Color Change | Mother's Leather Cleaner | Mothers | 4.5 Slight Color Change | Virox 5 Rtu | Diversey Inc. | 4.5 Slight Color Change |
| Ducky All Purpose Cleaner | Ducky Products, Inc. | 4.5 Slight Color Change | Oxivir TB Wipes | Diversey Inc. | 4.5 Slight Color Change | Wex Cide 128 (1:128 dilution) | Wexford Labs, Inc. | 4.5 Slight Color Change |

| | | |
|---|--|---------------------------|
| Cleaner results are rated on a scale of 1 - 5 | 1-3: Causes discoloration. Not recommended | 4-5: *Recommended for use |
|---|--|---------------------------|

*Cleaners only recommended if diluted per manufacturer's instructions.

Topical cleaners must be wiped off with clean water and dried with clean cloth following application.

The performance results shown in this chart are not guaranteed for all SII Vinyl and Polyurethane products.

The evaluations are indicators after laboratory tests and may not be indicative of field performance

Healthcare facilities maintain disinfecting regimens to reduce the spread of infections. There is a wide variety of available biocides that include bleaches, peroxides, and quaternary ammonium products, among others. They should always be used at the recommended dilution, never in concentrated form.

To prolong the life of digital or any other coated fabric, they should be rinsed off after the recommended residence time. It should be noted that misuse of disinfectants is the major source of surface deterioration. Spradling continually evaluates cleaners/disinfectants.

6/17/2016