



# APPROVED CLEANERS POLYURETHANE: DOLCE



PATTERNS INCLUDE: Dolce

Cleaner	Cleaner's Manufacturer	Polyurethane (Dolce)
303 Fabric/Vinyl Cleaner (dilution: 1/2 cup (4 oz) in 1 gallon water)	303 Products, Inc.	4.5 - Slight color change**
A&G Boat Wash & Multipurpose Cleaner (6:1 dilution)	A&G Industries, Inc.	N/A
All Purpose Vinyl Cleaner	CMI Vclean	4.5 - Slight color change**
Asepticare TB + II	Ecolab	Appreciable wear at Wyzenbeek 100,000 cycles - Not approved
Babe's Boat Care Wash (dilution: 1 oz per gallon of water)	Babe's Boat Care Products	Appreciable wear at Wyzenbeek 100,000 cycles - Not approved
Bio Kleen Amazing (dilution: 6 oz per gallon of water)	Bio Kleen Products Inc.	4.5 - Slight color change**
Caviwipes XL Packed	Metrex	4.5 - Slight color change**
Clorox Healthcare Bleach Germicidal Wipes	The Clorox Company	Not approved - Noticeable color and gloss change, as well as topcoat damage
Crystal Simple Green - dilution 1:30	Sunshine Makers, Inc.	4.5 - Slight color change**
Coverage Plus Germicidal Wipes	Spray Nine	4.5 - Slight color change**
Dispatch (1:10 Dilution)	Caltech Industries Inc.	Noticeable color change - Not approved
Ducky All Purpose Cleaner	Ducky Products, Inc.	Appreciable wear at 100,000 cycles - Not approved

Cleaner	Cleaner's Manufacturer	Polyurethane (Dolce)
Fabric Cleaner	Tekonsha Corp.	Not tested
Fantastik® Antibacterial All Purpose Cleaner Heavy Duty	S.C. Johnson & Son, Inc.	Appreciable wear at Wyzenbeek 100,000 cycles - Not approved
Finyl Fix Vinyl Cleaner - dilution: 0.5 oz / quart water	Neuco Seating Inc.	Not Approved - Surface damage
Formula 409® Antibacterial All-purpose cleaner	The Clorox Company	Appreciable wear at Wyzenbeek 100,000 cycles - Not approved
Four Star All Purpose Cleaner	Four Star	4.5 - Slight color change
Glance NA Diluted (1:50 water)	Diversey Inc.	Surface damage - not approved
GP Forward Diluted (1:64 water)	Diversey Inc.	4.5 - Slight color change**
Hydrogen Peroxide Cleaner Disinfectant Wipes	Clorox	4.5 - Slight color change**
Lysol Foaming Disinfectant Cleaner	Brand, IC	Appreciable wear at Wyzenbeek 100,000 cycles - Not approved
Mold & Mildew Stain Remover dilution: 1 scoop (1/2 oz) per quart water	losso Marine Products	Color change and surface damage - Not approved
Mother's Leather Cleaner	Mothers	Not tested
Oxivir TB Wipes	Diversey Inc.	4.5 - Slight color change**

Cleaner	Cleaner's Manufacturer	Polyurethane (Dolce)
Oxycide Diluted - 3 oz/gl in water	Ecolab	Not tested
Reposolv - Dilution: 1/40	American Continental Techlabs, LLC	4.5 - Slight color change**
Sanicloth AF 3	PDI	4.5 - Slight color change**
Simple Green Towels	Simple Green	4.5 - Slight color change**
Sodium Hypochlorite Disinfectant/Disinfectant Cleaner - Dilution: 0.5 oz / quart water	PCS - Process Cleaning Solutions	Discoloration - Not Approved
Stride Floral Neutral (1:32 water) - Daily cleaning (1:64 water- Cleaning excess dirt)	Diversey Inc.	4.5 - Slight color change**
Stride Fragrance Free Neutral Cleaner (1:266 water)	Diversey Inc.	4.5 - Slight color change**
Super S	Tekonsha Corp.	Surface damage - not approved
Super Sani-cloth	PDI	4.5 - Slight color change**
Vinyl Sauce	Boat Blins	Appreciable wear at Wyzenbeek 100,000 cycles - Not approved
Virex II 256 (1:256 Dilution)	Diversey Inc.	Appreciable wear at Wyzenbeek 100,000 cycles - Not approved
Virox 5 Rtu	Diversey Inc.	4.5 - Slight color change**
Wex Cide 128 (1:128 dilution)	Wexford Labs, Inc.	4.5 - Slight color change**

Cleaner results are rated on a scale of 1 - 5	1-3: Causes discoloration. Not recommended	4-5: *Recommended for use
---	--	---------------------------

\*Cleaners only recommended if diluted per manufacturer's instructions. Topical cleaners must be wiped off with clean water and dried with clean cloth following application. The performance results shown in this chart are not guaranteed for all SII Vinyl and Polyurethane products. The evaluations are indicators after laboratory tests and may not be indicative of field performance. Healthcare facilities maintain disinfecting regimens to reduce the spread of infections. There is a wide variety of available biocides that include bleaches, peroxides and quaternary ammonium products, among others. They should always be used at the recommended dilution, never in concentrated form. To prolong the life of digital or any other coated fabric, they should be rinsed off after the recommended residence time. It should be noted that misuse of disinfectants is the major source of surface deterioration. Spradling continually evaluates cleaners/disinfectants. \*\*Samples showed slight wear at Wyzenbeek 100,000 cycles