



# APPROVED CLEANERS

## POLYURETHANE: BALLISTIC



PATTERNS INCLUDE: Ballistic

| Cleaner   | Cleaner's Manufacturer    | Polyurethane (Ballistic)                                 |
|---|---------------------------|--|
| 303 Fabric/Vinyl Cleaner (dilution: 1/2 cup (4 oz) in 1 gallon water) | 303 Products, Inc.        | 4.5 - Slight color change                                |
| A&G Boat Wash & Multipurpose Cleaner (6:1 dilution)                   | A&G Industries, Inc.      | N/A  |
| All Purpose Vinyl Cleaner   | CMI Vclean                | 4.5 - Slight color change                                |
| Asepticare TB + II  | Ecolab                    | 4.5 - Slight color change                                |
| Babe's Boat Care Wash (dilution: 1 oz per gallon of water)            | Babe's Boat Care Products | 4.5 - Slight color change                                |
| Bio Kleen Amazing (dilution: 6 oz per gallon of water)                | Bio Kleen Products Inc.   | 4.5 - Slight color change                                |
| Caviwipes XL Packed   | Metrex                    | 4.5 - Slight color change                                |
| Clorox Healthcare Bleach Germicidal Wipes                             | The Clorox Company        | Not approved- Noticeable color change and topcoat damage |
| Crystal Simple Green - dilution 1:30                                  | Sunshine Makers, Inc.     | 4.5 - Slight color change                                |
| Coverage Plus Germicidal Wipes  | Spray Nine                | 4.5 - Slight color change                                |
| Dispatch (1:10 Dilution)  | Caltech Industries Inc.   | Appreciable wear at 100,000 cycles - Not approved        |
| Ducky All Purpose Cleaner   | Ducky Products, Inc.      | 4.5 - Slight color change                                |
| Fabric Cleaner  | Tekonsha Corp.            | Not tested   |

| Cleaner  | Cleaner's Manufacturer   | Polyurethane (Ballistic)               |
|--|--------------------------|--|
| Fantastik® Antibacterial All Purpose Cleaner Heavy Duty                | S.C. Johnson & Son, Inc. | Noticeable color change - Not approved |
| Finyl Fix Vinyl Cleaner - dilution: 0.5 oz / quart water               | Neuco Seating Inc.       | 4.5 - Slight color change**            |
| Formula 409® Antibacterial All-purpose cleaner                         | The Clorox Company       | Topcoat damage - Not approved          |
| Four Star All Purpose Cleaner  | Four Star                | 4.5 - Slight color change              |
| Glance NA Diluted (1:50 water)   | Diversey Inc.            | 4.5 - Slight color change              |
| GP Forward Diluted (1:64 water)  | Diversey Inc.            | 4.5 - Slight color change              |
| Hula Boat Chill Mold Retardant Concentrated                            | Hula Boat Care           | 4.5 - Slight color change              |
| Hydrogen Peroxide Cleaner Disinfectant Wipes                           | Clorox                   | 4.5 - Slight color change              |
| Lysol Foaming Disinfectant Cleaner                                     | Brand, IC                | 4.5 - Slight color change              |
| Mold & Mildew Stain Remover dilution: 1 scoop (1/2 oz) per quart water | losso Marine Products    | 4.5 - Slight color change              |
| Mother's Leather Cleaner   | Mothers                  | Not tested                             |
| Oxivir TB Wipes  | Diversey Inc.            | 4.5 - Slight color change              |
| Oxycide Diluted - 3 oz/gl in water                                     | Ecolab                   | Not tested                             |

| Cleaner  | Cleaner's Manufacturer             | Polyurethane (Ballistic)      |
|--|------------------------------------|-------------------------------|
| Reposolv - Dilution: 1/40  | American Continental Techlabs, LLC | 4.5 - Slight color change**   |
| Sanicloth AF 3   | PDI                                | 4.5 - Slight color change     |
| Simple Green Towels  | Simple Green                       | 4.5 - Slight color change     |
| Sodium Hypochlorite Disinfectant/Disinfectant Cleaner - Dilution: 0.5 oz / quart water | PCS - Process Cleaning Solutions   | 4.5 - Slight color change**   |
| Stride Floral Neutral (1:32 water) - Daily cleaning (1:64 water-Cleaning excess dirt)  | Diversey Inc.                      | 4.5 - Slight color change     |
| Stride Fragrance Free Neutral Cleaner (1:266 water)                                    | Diversey Inc.                      | 4.5 - Slight color change     |
| Super S  | Tekonsha Corp.                     | 4.5 - Slight color change     |
| Super Sani-cloth   | PDI                                | 4.5 - Slight color change**   |
| Vinyl Sauce  | Boat Blins                         | 4.5 - Slight color change     |
| Virex II 256 (1:256 Dilution)  | Diversey Inc.                      | Surface damage - Not Approved |
| Virox 5 Rtu  | Diversey Inc.                      | 4.5 - Slight color change     |
| Wex Cide 128 (1:128 dilution)  | Wexford Labs, Inc.                 | 4.5 - Slight color change     |

|   |  |                           |
|---|--|---------------------------|
| Cleaner results are rated on a scale of 1 - 5 | 1-3: Causes discoloration. Not recommended | 4-5: *Recommended for use |
|---|--|---------------------------|

\*Cleaners only recommended if diluted per manufacturer's instructions. Topical cleaners must be wiped off with clean water and dried with clean cloth following application. The performance results shown in this chart are not guaranteed for all SII Vinyl and Polyurethane products. The evaluations are indicators after laboratory tests and may not be indicative of field performance. Healthcare facilities maintain disinfecting regimens to reduce the spread of infections. There is a wide variety of available biocides that include bleaches, peroxides and quaternary ammonium products, among others. They should always be used at the recommended dilution, never in concentrated form. To prolong the life of digital or any other coated fabric, they should be rinsed off after the recommended residence time. It should be noted that misuse of disinfectants is the major source of surface deterioration. Spradling continually evaluates cleaners/ disinfectants. \*\*Samples showed slight wear at Wyzenbeek 100,000 cycles